

PARTS LIST					PARTS LIST				
Item	Part Code	QTY.	Part No./File Name	Description	Item	Part Code	QTY.	Part No./File Name	Description
1	78304	1	8-3088	Rear Cut-off Die	69	63949	4	8-32_.88sh	#8-32 x 7/8" Socket Hd Cap Screw
2	72810	1	8A-3073	Front Cut-off Die	70	63213	2	8-32_1.00sh	#8-32 x 1" Socket Hd Cap Screw
3	78300	1	9-3088	Wire Anvil	71	63158	4	3.16_.50dp	Ø 3/16" x 1/2" Dowel Pin
4	78301	1	9A-3088	Insulation Anvil	72	63194	1	3.16_10-32_.50 shs	3/16" x 1/2" x 10-32 Shoulder Screw
5	76602	1	12-3039	Cut-off Punch	73	63470	4	3.16_.75dp	3/16" x 3/4" Dowel Pin
6	72815	1	12A-3073	Cut-off Punch Spacer	74	63473	1	10-32_.25sh	#10-32 x 1/4" Socket Hd Cap Screw
7	78302	1	13-3088	Wire Rolling Tool	75	63054	3	10-32_.25ss	#10-32 x 1/4" Socket Hd Set Screw
8	78303	1	14-3088	Insulation Rolling Tool	76	78993	2	10-32_.38bh	#10-32 x 3/8" Button Hd Cap Screw
9	74218	1	34-3037	Wire Crimp Dial	77	71626	4	10-32_.38ss	#10-32 x 3/8" Socket Hd Set Screw
10	76768	1	158S-3001	IRT Spacer	78	76501	8	10-32_.50bh	#10-32 x 1/2" Button Hd Cap Screw
11	75285	1	199-3001	Guard	79	70293	1	10-32_.63sh	#10-32 x 5/8" Socket Hd Cap Screw
12	72807	1	200-3073	Baseplate	80	70925	2	10-32_.88sh	#10-32 x 7/8" Socket Hd Cap Screw
13	78299	1	250-3088	Feed Plate	81	63155	2	10-32_1.00sh	#10-32 x 1" Socket Hd Cap Screw
14	72804	1	303-3073	Feed Finger	82	63826	2	10-32_1.50sh	#10-32 x 1 1/2" Socket Hd Cap Screw
15	71916	1	403-3088	Brake Shoe	83	63632	3	1.4-20_.50bh	1/4-20 x 1/2" Button Hd Cap Screw
16	72805	1	500-3073	Left Guide Rail	84		2	1.4_.75dp	1/4" x 3/4" Dowel Pin
17	72806	1	1000-3073	Right Guide Rail	85	63055	1	5.16-18_1.00bh	5/16-18 x 1" Button Hd Cap Screw
18	75287	1	1600-3011	Stripper					
19	74491	2	GS-375	Guard Spacer					
20	74343	1	MX3	Ram					
21	74346	1	MX6	Gear Arm					
22	74347	1	MX7	Cam Pin					
23	74350	1	MX8	Cam Roller					
24	74352	2	MX11	Gib					
25	74356	1	MX12	Feed Finger Pivot Pin					
26	74360	1	MX13	Adjusting Bar					
27	74364	1	MX16	Retainer					
28	74376	1	MX25	Stroke Adjustment Screw					
29	74407	1	MX33	Mounting Post					
30	74409	1	MX35	Insulation Dial					
31	74411	1	MX36	Dial Spacer					
32	74412	1	MX44	Locating Dowel					
33	74418	1	MX49	Tool Retainer					
34	74419	3	MX50	Safety Pivot Pin					
35	74420	2	MX52	Pivot Pin					
36	74908	1	MX54-R	Slide Support					
37	74909	1	MX58-R	Frame					
38	74912	1	MX69-R	Upper Rack Pad					
39	74913	1	MX70-R	Lower Rack Pad					
40	74914	1	MX71-R	Cam Rack					
41	72285	1	MX72-R-1	Swing Arm					
42	72287	1	MX73-R-1	Feed Arm					
43	74915	1	MX75-R	Cam, 1 5/8" Downstroke					
44	72596	1	MX80-1-R	Feed Finger Spring					
45	74521	1	MX89-R	Cam, 1 1/8" Upstroke					
46	74820	1	MX91-R	Lifter Plate					
47	74821	2	MX92-R	Brake Support					
48	74822	2	MX93-R	Lifter					
49	74823	1	MX94-R	Brake Shaft					
50	74825	1	MX96-R	Brake Handle					
51	74827	2	MX97-R	Retaining Ring					
52	72286	1	MX99-R-1	Spacer					
53	74917	1	MX100-R	Spring Bracket					
54	76682	1	MX101-R	Cam, 1 5/8" Upstroke					
55	72204	1	MX102-R	Cam (K Press Down Stroke)					
56	72310	1	MX104	Wave Disc Spring					
57	75083	2	Irving 3100-18	External Retaining Ring					
58	75342	2	LC-045E-6-M	Brake Spring					
59	74611	1	LE-037CD-6	Extension Spring					
60	70739	2	McMaster-Carr #3126A53	Spring Plunger					
61	73785	2	SPI 99-602-5	#10 Black Knurled Knob					
62	62294	1	1.16_.75rp	1/16" x 3/4" Roll Pin					
63	62040	1	1.8_1.00rp	1/8" x 1" Roll Pin					
64	63207	2	6-32_.25sh	#6-32 x 1/4" Socket Hd Cap Screw					
65	63212	1	8-32_.25bh	#8-32 x 1/4" Button Hd Cap Screw					
66	61472	4	8-32_.38bh	#8-32 x 3/8" Button Hd Cap Screw					
67	63508	2	8-32_.38fh	#8-32 x 3/8" Flat Hd Cap Screw					
68	63161	4	8-32_.38sh	#8-32 x 3/8" Socket Hd Cap Screw					

NOTE: ITEMS MARKED IN BOLD TEXT ARE HIGH WEAR ITEMS

