


Parts List					Parts List				
Item	Part Code	QTY.	Part No./File Name	Description	Item	Part Code	QTY.	Part No./File Name	Description
1	61929	1	9-4011	Wire Anvil	69	78835	1	MX360-ITD-S	Scrap Retainer
2	76679	1	9A-4004	Insulation Anvil	70	72317	1	Clippard #12296	Cam Follower
3	61928	1	13-4011	Wire Rolling Tool	71	72318	1	Clippard MJV-3	3-Way Valve
4	76659	1	14-4004	Insulation Rolling Tool	72	78719	1	LC-051D-11-M	Compression Spring
5	73888	2	GS-125	Guard Spacer	73	72315	1	LC-022A-4	Compression Spring
6	71494	1	MX2A-S-1	Mounting Frame	74	78681	2	LC-029B-3-M	Compression Spring
7	71030	1	MX2B-S	Plunger Frame	75	74611	1	LE-037CD-6	Extension Spring
8	74343	1	MX3	Ram	76	70739	2	McMaster-Carr #3126A53	Spring Plunger
9	74438	1	MX5-S	Cam Rack	77	74447	1	McMaster-Carr #98296A109	Expansion Pin (1/16 x 1/2")
10	74346	1	MX6	Gear Arm	78	72069	2	McMaster Carr #98407A118	#8 E-Style Retaining Ring
11	74347	1	MX7	Cam Pin	79	72352	3	Pisco PL250-N1U	Ø1/4" x 1/8-NPT Elbow Fitting
12	74350	1	MX8	Cam Roller	80	73222	1	Pisco PC250-N1U	1/4" x 1/8" NPT Straight
13	74351	2	MX10-S	Rack Pad	81	63200	2	Truarc #5555-12	Retaining Ring
14	74352	2	MX11	Gib	82	63201	2	Vlier #PH-51-P	Spring Plunger
15	74356	1	MX12	Feed Finger Pivot Pin	83	63202	2	4lw	#4 Lock Washer
16	74360	1	MX13	Adjusting Bar	84	63203	2	4-40_13bh	#4-40 x 1/8" Button Hd Cap Screw
17	76868	1	MX14-1-S	Feed Finger Arm	85	63204	2	4-40_16sh	#4-40 x 5/32" Socket Hd Cap Screw
18	76874	1	MX15-1-S	Feed Finger Guide	86	63205	1	1.8_38rp	Ø 1/8" x 3/8" Roll Pin
19	74364	1	MX16	Retainer	87	63053	2	1.8_63rp	1/8" x 5/8" Roll Pin
20	71495	1	MX18-S-1	Swing Arm	88	62040	1	1.8_1.00rp	1/8" x 1" Roll Pin
21	74376	1	MX25	Stroke Adjustment Screw	89	63206	2	5-40_19ssf	#5-40 x 3/16" Socket Set Screw
22	74407	1	MX33	Mounting Post	90	63207	5	6-32_25sh	#6-32 x 1/4" Socket Hd Cap Screw
23	72042	1	MX34-E	Wire Crimp Dial	91	63209	6	6-32_38sh	#6-32 x 3/8" Socket Hd Cap Screw
24	74409	1	MX35	Insulation Dial	92	63210	2	8fw	#8 Flatwasher
25	74411	1	MX36	Dial Spacer	93	63211	2	8-32_13ssf	#8-32 x 1/8" Socket Hd Set Screw
26	74412	1	MX44	Locating Dowel	94	63212	1	8-32_25bh	#8-32 x 1/4" Button Hd Cap Screw
27	74415	1	MX45-S	Feed Finger Spring	95	63052	2	8-32_50fh	#8-32 x 1/2" Flat Hd Cap Screw
28	74419	3	MX50	Safety Pivot Pin	96	63164	2	8-32_50sh	#8-32 x 1/2" Socket Hd Cap Screw
29	71493	2	MX52-S-1	Pivot Pin	97	63162	2	8-32_63sh	#8-32 x 5/8" Socket Hd Cap Screw
30	74614	1	MX90-S	Spring Bracket	98	63213	1	8-32_1.00sh	#8-32 x 1" Socket Hd Cap Screw
31	72310	1	MX104	Wave Disc Spring	99	63158	4	3.16_50dp	Ø 3/16" x 1/2" Dowel Pin
32	71678	1	MX105-S	Pivot Pin Plate	100	63470	12	3.16_75dp	Ø 3/16" x 3/4" Dowel Pin
33	70865	1	MX301-4-ITD-S	Latching Gate	101	78517	2	10lw	#10 Lockwasher
34	72261	1	MX302-1-ITD-S	Base Plate	102	63531	2	10-24_38bh	#10-24 x 3/8" Button Hd Cap Screw
35	76563	2	MX304-ITD-S	Hinge Pin	103	78327	1	10-32_13bh	#10-32 x 1/8" Button Hd Cap Screw
36	76564	2	MX305-ITD-S	Pin	104	63054	2	10-32_25ss	#10-32 x 1/4" Socket Hd Set Screw
37	76566	1	MX307-ITD-S	Stock Chute	105	78993	8	10-32_38bh	#10-32 x 3/8" Button Hd Cap Screw
38	76567	1	MX308-ITD-S	Latch Pivot Pin	106	70110	1	10-32_38sh	#10-32 x 3/8" Socket Hd Cap Screw
39	78936	1	MX309-4-ITD-S	Cut-off Keeper	107		4	10-32_38ssf	#10-32 x 3/8" Socket Hd Set Screw
40	72257	1	MX310-1-ITD-S	Die Holder	108	63056	2	10-32_50sh	#10-32 x 1/2" Socket Hd Cap Screw
41	76570	1	MX311-ITD-S	Left Feed Shim (1/4")	109	76501	4	10-32_50bh	#10-32 x 1/2" Button Hd Cap Screw
42	72259	1	MX313-1-ITD-S	Insulation Pusher for 1/4" Terminal	110	70293	1	10-32_63sh	#10-32 x 5/8" Socket Hd Cap Screw
43	76573	1	MX314-ITD-S	Catch	111	63532	2	10-32_75sh	#10-32 x 3/4" Socket Hd Cap Screw
44	76574	1	MX315-ITD-S	Insulation Tool Spacer	112	63827	2	1.4_50dp	Ø 1/4" x 1/2" Dowel Pin
45	76575	2	MX316-ITD-S	Latch Spring	113	63632	3	1.4-20_50bh	1/4-20 x 1/2" Button Hd Cap Screw
46	76576	1	MX317-ITD-S	Base Plate Spacer	114	63055	1	5.16-18_1.00bh	5/16-18 x 1" Button Hd Cap Screw
47	76578	1	MX319-ITD-S	Knock off	115	71086	1	5.16-24_75ssf	5/16-24 x 3/4" Socket Hd Set Screw
48	76579	1	MX320-ITD-S	Brake	116	78687	2	10-32_25bh	#10-32 x 1/4" Button Hd Cap Screw
49	76580	1	MX321-ITD-S	Brake Actuator	117		1	15.32_32 hex nut	Hex Nut
50	76583	1	MX324-ITD-S	Cut-off Pad Pusher	118		1	1.2isw	1/2" Internal Star Washer
51	78935	1	MX326-4-ITD-S	Cut-off Pad					
52	76586	1	MX327-ITD-S	Left Feed Rail					
53	76587	1	MX328-ITD-S	Hold Down Spring					
54	76588	1	MX329-ITD-S	Right Feed Rail					
55	76589	1	MX330-ITD-S	Feed Plate					
56	76590	1	MX331-ITD-S	Latch (Automatic)					
57	76591	1	MX332-ITD-S	Support					
58	76592	1	MX333-ITD-S	Latch (1/4" Wire Stop)					
59	76608	1	MX335-ITD-S	Cam					
60	76661	1	MX337-ITD-S	Feed Finger (fed between carrier and inslu ear)					
61	71686	1	MX337-2-ITD-S	Feed Finger (fed in carrier strip hole)					
62	72233	1	MX338-1-ITD-S	Arm Switch Cam (1 1/8" Stroke)					
63	70745	1	MX339-ITD-S	Guard					
64	72260	1	MX344-1-ITD-S	Leaf Spring					
65	72099	1	MX348-ITD-S	.550 Strike Slide Cylinder					
66	72893	1	MX357-ITD-S	Bracket					
67	78733	1	MX358-1-ITD-S	Valve Mounting Plate					
68	61993	1	MX358-2-ITD-S	Valve Mounting Plate					

NOTE: ITEMS MARKED IN BOLD TEXT ARE HIGH WEAR ITEMS

NOTE:
 (1) Items marked in bold text are high wear items.
 (2) Use OEM replacement tooling only.
 (3) Recommended machine speed for automatic equipment is a maximum of 3500 parts per hour.



REV	PART No.	DESCRIPTION	MATERIAL SPECIFICATION	QTY	OFF REC'D
B	ECR# 3894 SCJ	#1875	PD265N		
A	Updated valve ass'y SCJ	#1873			

DO NOT SCALE DRAWING		UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:	
FRACTIONS	DECIMALS	ANGLES	
±1/64	±0.010	±1/2°	
±1/32	±0.005	±1/4°	

DATE	BY	CHK'D BY	APP. BY
21Mar05	JT		