Parts List				
Item No.	Part Code	Part No.	Description	QTY.
1	61745	8A-6000	Front Cut-off Pad Retainer	1
2	**61942**	**9-6016**	**Conductor Anvil (F260)**	**1**
3	**62292**	**9-6024**	**Conductor Anvil (F265)**	**1**
4	**61943**	**9A-6016**	**Insulation Anvil**	**1**
5	**61747**	**12A-6000**	**Cut-off Pad**	**1**
6	**62291**	**13-6024**	**Wire Rolling Tool (F265)**	**1**
7	**61907**	**13-6015**	**Wire Rolling Tool (F260)**	**1**
8	**61908**	**14-6015**	**Insulation Rolling Tool**	**1**
9	61748	15-6000	Cut-Off Pad Driver	1
10	61626	26-6000	Guard Bracket	1
11	61944	26-6016	Mounting Block	1
12	61945	26A-6016	Adjustable Guide	1
13	76403	199-3005	Safety Guard	1
14	61939	250-6016	Feed Plate	1
15	61664	303-6003	Feed Finger	1
16	61941	500-6016	Rear Guide	1
17	61542	MM1-S	Frame	1
18	61543	MM2-S	Base Plate	1
19	61545	MM3-S	Plunger	1
20	61762	MM6-S-1	Front Guide	1
21	61549	MM7-S	Brake	1
22	61550	MM8-S	Brake Lever	1
23	61551	MM9-S	Adjustment Screw Retainer	1
24	61552	MM10-S	Adjustment Screw	1
25	61553	MM11-S	Brake Spring	2
26	61554	MM12	Adjustable Feed Piston	1
27	61555	MM13	Cam Roller	1
28	61556	MM14	Piston Spring	1
29	61557	MM15	Spring Plate	1
30	61558	MM16	Feed Adjustment Block	1
31	61559	MM17	Feed Adjustment Screw	1
32	61560	MM18	Retainer	1
33	61561	MM19	Guide Block	1
34	61562	MM20	Feed Washer	1
35	61563	MM21	Feed Finger Spring	1
36	61564	MM22	Feed Finger Shaft	1
37	61565	MM23	Feed Arm	1
38	61566	MM24	Feed Finger Retainer	1
39	61573	MM31	Post-feed Cam	1
40	61574	MM32	Pre-Feed Cam	1
41	61581	MM37-S	Tool Block	1
42	61583	MM39	Gib	2
43	61585	MM43	Counter Ass'y.	1
44	61586	MM44	Locator Pin	1
45	61588	MM47	Dog Screw	1
46	61590	MM48	IRT Adjustment Block	1
47	61591	MM49	Tool Holder	1
48	61912	MM49-5	Tool Holder	1
49	61592	MM50-S	Stripper Spacer	1
50	61593	MM51-S	Stripper	1
51	61595	MM56	Retaining Ring	1
52	61598	MM59	ID Plate	1
53	61596	MM57	Continuous Regulation Head Assembly	1
54	61597	MM58	Protection Spacer	1
55	60601	LC-032C-8	Spring	1
56	72069	McMaster Carr #98407A122	#10 E-Style Retaining Ring	2
57		M3x0.5_5.0sh	M3 x 5mm Socket Hd Cap Screw	2
58		M3x0.5_16.0sh	M3 x 0.5 x 16mm Socket Hd Cap Screw	1
59		M4x.7_8.0bh	M4 x .7 x 8mm Button Hd Cap Screw	3
60		M4x0.7_8.0sh	M4 x .7 x 8.0 Socket Hd Cap Screw	3
61		M5_18.0dp	M5 x 18mm Dowel Pin	1
62		M5_M3.9err	M5 External Retaining Ring	2
63	63521	M5x.8_10.0sh	M5 x .8 x 10mm Socket Hd Cap Screw	2
64		M5x.8_16.0sh	M5 x .8 x 16mm Socket Hd Cap Screw	5
65		M5x.8_12.0sh	M5 x .8 x 12mm Socket Hd Cap Screw	3
66		M5x.8_35.0sh	M5 x .08 x 35mm Socket Hd Cap Screw	3

Parts List				
Item No.	Part Code	Part No.	Description	QTY.
67		M6_10shss	M6 x 10mm Socket Hd Shoulder Screw	2
68		M6x1.0_12.0bh	M6 x 1.0 x 12mm Button Hd Cap Screw	1
69		M6x1.0_16.0bh	M6 x 1.0 x 16mm Button Hd Cap Screw	2
70		M6x1.0_40.0sh	M6 x 1.0 x 40mm Socket Hd Cap Screw	1
71		M6_18dp	M6 x 18mm Dowel Pin	1
72		M6_20dp	M6 x 20mm Dowel Pin	2
73		M6_In	M6 Lock Nut	1
74	62092	M8 x1.25 _35.0bh	M8 x 1.25 x 35mm Button Hd Cap Screw	1
75		M8_In	M8 Lock Nut	2

Note:

1) Items marked in "Bold Italic" are high wear components.
2) Use OEM replacement tooling only.



| | | | |